

Available for:

BLES8W-2, BLES-3, BLCS

Double Fold Bias Binder

Item No: B0421S03A 1-1/8 inch (28mm) Item No: B0421S02A 1-1/2 inch (36mm)

Stitches Used:

Chain Stitch - C1, C2 or C3 Needle Position Narrow Right Cover Stitch C1-C2 or C2-C3

Type of Application: Binding the edge of projects. Sewing Speed: Slow to moderate

Fabrics Used: Lightweight to medium weight woven fabrics cut on Bias.

INSTRUCTIONS:

Stitch Length: 3-4 Upper Looper:Down Upper Knife: Disengaged "LOCKED" Sewing Table: On

Bias Strip Cut Size:

1-1/8 inch Binder: Cut 1-1/8 inch bias from fine fabrics such as calico, muslin, etc.

Cut 1 inch wide for medium weight fabrics such as trigger. It. wt. denim.

1-1/2 inch Binder: Cut 1-3/8 inch for fine fabrics such as calico, muslin, etc.

Cut 1-1/4 inch wide for medium weight fabrics such as trigger, lt. wt. denim.

Test with fabric strip to make sure of correct width of bias.

- 1. Secure attachment to table with guide fixing screws.
- 2. Cut fabric strips to size needed.
- 3. Raise presser foot. With the point of the bias strip, place strip into attachment. Use tweezers to feed the strip into the attachment.
- 4. Place the folded bias up to the needles and under the presser foot.
- 5. Turn the hand wheel 3-4 times to secure the stitching in the fabric.
- 6. Place the fabric that is to be bound into the slot of the attachment. Place in the folded bias in front of the presser foot.
- 7. Loosen the guide fixing screws and move the attachment right or left to align the attachment with the needle position.
- 8. Sew test for proper alignment before sewing on project.

